

## **Ilkley canopy fitting instructions**

1. Drill through bottom flange of brackets, and also at 400mm centres along flange which runs along bottom between brackets.
2. Position bottom canopy section centrally above opening, and ensure that it is level.
3. Mark holes on wall and lift canopy down.
4. Drill & plug fixing holes, into solid brick.
5. Secure bottom section to wall.
6. Drill top upstand of top section of canopy at approx 400mm centres.
7. Lift into position on secured bottom section and mark holes on wall.
8. Lift top section down, and drill & plug marked holes.
9. Apply silicone along mating flange of bottom section, and lift top section into position.
10. Fasten to wall.
11. Wipe down canopy to remove dust, using warm soapy water.

Your Ilkley canopy will give years of maintenance free service, and simply requires an occasional wipe with warm soapy water.

*NB Do not use abrasive cleaners or solvent solutions to clean this canopy.*